

Transmit Frequency Modification Installation Instructions:

The following transmit frequency unlock software works with PowerSDR version 2.7.0 and greater

1. Ensure proper installation and operation of your Flex-Series radio using PowerSDR.
2. Close the PowerSDR software on your computer if running
3. Make sure your radio is powered on
4. Start the TURFClient.exe software. The program will find your radio, check for proper authorization, and unlock your radio.
5. Cycle the power on your radio when prompted.
6. Congratulations! Your FLEX-Series radio will be unlocked.